

# INSTRUCTIONS FOR

## Bin Hanging System (#18720)



**Step 1.** Mark holes in desired location (recommended to hit studs in four corners).



**Step 2.** Drill pilot holes in the wall panel.



**Step 3.** Screw into studs or anchors in drywall. (Hardware is not included)  
Then place provided hanging rails.

**Call Free 1.800.848.1633 • Fax Free 1.800.447.2923**  
Web: [GoHCL.com](http://GoHCL.com) • Email: [hcl@GoHCL.com](mailto:hcl@GoHCL.com)