

# ASSEMBLY INSTRUCTIONS FOR Storage Bin Cabinet (#5131)



**Step 1.** Start by laying the cabinet down on the floor.



**Step 2.** Line the 1st panel up with the pre-drilled holes starting at the top, and use a screw and washer configuration to secure. (NOTE - make sure louvered panels are upright.)



**Step 3.** Overlap the panels so that the two holes in the picture are on top of each other and repeat step 2.



**Step 4.** Repeat steps 2 and 3 until all of the panels are secured into position.

**Step 5.** With additional help, stand the unit upright and place the unit against the wall. Do not attempt to lift the unit by yourself.