

INSTRUCTIONS FOR PEEL AWAY MAT (HCL #7384)

INSTALLATION INSTRUCTIONS

1. Prepare The Location.
The Tacky Mat should be positioned in the entryway to assure contact with all foot or wheel-borne contaminants. **Clean** and **dry** the area where the mat is to be placed.
2. Remove Protective Film From Bottom
Pull white tab to remove bottom layer.
3. Adhere Mat To Floor
Align mat by touching one corner only. If position is correct, lower entire mat. Use a smooth, even force to assure that the entire mat is in contact with surface. Walk on mat (while top protective layer is still on) to apply additional pressure to be certain entire mat is in contact – especially the edges.
4. Peel Off Top Protective Film
The Tacky Mat is now ready for use.
5. Watch For Particulate Build-up
When mat is visibly dirty, peel off top layer. A new, clean layer is exposed.

