

# ASSEMBLY INSTRUCTIONS FOR Stainless Steel Label Dispensers (#2504-01, 2507, 2506-01)



**Step 1.** Place the label guide on the front of the dispenser by sliding the guide edge onto the dispenser front panel.



**Step 2.** Drop your blister pack or open roll of labels into one of the dispenser slots.



**Step 3.** Pull out the first few labels on the roll and slide them down into the label guide on the front of the dispenser.



**Step 4.** Shut the lid and pull the labels and backing until a label is automatically peeled and dispensed below the top lid.

Call Free 1.800.848.1633 or 1.888.HCL-INTL Fax Free 1.800.447.2923  
Website: [www.HealthCareLogistics.com](http://www.HealthCareLogistics.com) • Email: [hcl@HealthCareLogistics.com](mailto:hcl@HealthCareLogistics.com)