

ASSEMBLY INSTRUCTIONS FOR

Refrigerator Locking Kit (#17673)

Refrigerator Door Lock Installation Instructions:

Prior to removing the adhesive backing paper, practice placing the anchor clips with the padlock installed to test alternate attachment points. Check for clearances and cable alignment. One cable pad is installed on the side of the refrigerator, with the other cable piece on the door. For Side-by-side units, install one cable piece on the topside of the fridge, and the cable on the swinging door.



1. Locate a suitable location across the door openings being secured. You will need 2" x 3" inches of space for each pad. Use a pencil to trace around the security plate once the location is decided. (See picture)
2. Clean and prepare chosen pad locations with the included kit. Use the scrubby pad to clean the attachment location, wipe area clean with the alcohol swab. Let dry completely.
3. Peel the adhesive backing paper. Do not touch the exposed pad. Place security plates onto selected locations, and hold in place **FIRMLY** for about 2 minutes. Bonding is immediate, but full adhesive strength is not achieved for 48 hours. **Please wait 24hours before installing lock or putting any tension on the cables.**

Call Free 1.800.848.1633 or 1.888.HCL-INTL Fax Free 1.800.447.2923
Website: www.HealthCareLogistics.com • Email: hcl@HealthCareLogistics.com